

# HENRY®

The Professional's Formula For Success™



## HENRY® 377 Carpet Pad Adhesive



Premium, installer-grade carpet pad adhesive for the installation of all residential carpet padding.

**Use for:** The installation of all types of carpet pads, including jute, hair, rubber, urethane, and also offers excellent rebond capabilities.

### Key Features & Benefits:

- Quick Tack – install carpet pad immediately
- Strong Bond – prevents carpet pad from slipping
- Quick Dry time – 2 hours

### Bonds To:

**Porous:** Concrete, well-bonded cementitious underlayments, APA grade underlayment plywood (untreated) and radiant-heated subfloors where temperatures do not exceed 85°F (29.4°C) on all grade levels. Also can be used over well-bonded, properly primed gypsum underlayments (above-grade only). Also can be used over well-bonded, properly primed gypsum underlayments (above-grade only).

**Non-porous:** Existing resilient flooring on all grade levels as recommended by the carpet pad manufacturer. Please note that all substrates must be sound, solid and well-bonded.

PLEASE READ FULL TECHNICAL BROCHURE AND SDS BEFORE  
INSTALLING ([WWW.WWHENRY.COM](http://WWW.WWHENRY.COM))



# HENRY®

The W.W. Henry Company  
(888) 512-7339

[www.wwhenry.com](http://www.wwhenry.com)