



ARDEX TECHNICAL UPDATE

Update 57

May 21, 2015

To: ARDEX Sales Professionals, Sales Managers, Corporate (select)

From: ARDEX Technical Department

Shaw Ecoworx Broadloom Carpet

Upon completion of testing and consultation with Research & Development, this will confirm that HENRY 351 is approved for the installation of Shaw broadloom carpet with the Ecoworx backing.

Installations using HENRY 351 must use the 1/8" x 1/8" x 1/16" notched trowel and the adhesive must be permitted to remain open ten (10) minutes prior to setting the carpet into the adhesive. Additional installation recommendations, as detailed in the HENRY 351 Technical Data Sheet, remain valid.

Please note that this recommendation does not extend to the installation of Shaw carpet tiles with the Ecoworx backing. For installing Shaw carpet tiles with the Ecoworx backing, the correct adhesive recommendation remains HENRY 630.

Should you have any questions on this information, please contact the ARDEX Technical Service Department.

A handwritten signature in black ink, appearing to read "T. Schneider".

Tivona Schneider

Technical Communications Supervisor

ARDEX AMERICAS 400 ARDEX Park Drive Aliquippa PA 15001

P: 724-203-5000 F: 724-203-5001 www.ardexamericas.com