

HENRY®

The Professional's Formula For Success™

377 Carpet Pad Adhesive

For all residential carpet pads, including jute, hair, rubber, urethane or rebond over a variety of substrates.

- Low odor
- Low VOC
- No reportable hazardous substances
(per OSHA 29 CFR 1910.1200)
- Nonflammable
- No organic solvents

Size Available:

1 Gallon (3.78 L)

Coverage:

500-600 lin. ft. (152-182 lin. m)
per package at 1/8" bead



GREENLINE
ENVIRONMENTAL TECHNOLOGY

The W.W. Henry Company
400 Ardex Park Drive
Aliquippa, PA 15001
(724) 203-8000 (Phone)
1-800-232-4832 (Phone)
(724) 203-5001 (Fax)
www.wwhenry.com

HENRY[®] 377

Carpet Pad Adhesive

Description

A premium, installer-grade adhesive for the installation of all residential carpet padding, including jute, hair, rubber, urethane, or rebond.

Use For

All residential carpet pads, including jute, rubber, urethane or rebond.

Bonds To

Refer to the flooring manufacturer's specific recommendations for suitable substrates.

- **Porous:** Concrete, well-bonded cementitious underlayments, APA grade underlayment plywood (untreated) and radiant-heated subfloors where temperatures do not exceed 85°F (29.4°C) on all grade levels. Also can be used over well-bonded, properly primed gypsum underlayments (above-grade only). Also can be used over well-bonded, properly primed gypsum underlayments (above-grade only).
- **Non-porous:** Existing resilient flooring on all grade levels as recommended by the carpet pad manufacturer. Please note that all substrates must be sound, solid and well-bonded.

Preparation

- Refer to the flooring manufacturer's specific recommendations.
- Acclimate the installation area, adhesive and flooring in an enclosed building at a minimum of 65°F (18°C) for at least 48 hours before, during and for 48 hours after installation.
- Substrate must be sound, smooth and flat in accordance with the flooring manufacturer's recommendations. Ensure that the substrate is solid and securely fixed to provide a rigid base free of undue flex. All loose wood must be re-nailed to create a sound surface. Patching and/or leveling materials must have a minimum compressive strength of 3,000 psi.
- Substrate must be clean, dry and free of excess moisture and alkali. Mechanically remove dirt, wax, grease, paints, oils, sealers, curing compounds and all foreign matter that would interfere with proper adhesion. Please note that when removing existing flooring, any asbestos-containing materials should be handled and disposed of in accordance with applicable federal, state and local regulations.

Installation

Refer to carpet pad manufacturer's specific recommendations. Open flip-top lid. Apply adhesive 3-4 inches away from each wall in a crisscross pattern, and then apply additional adhesive under and parallel to all pad seams. Slight hand pressure on the side of the container will help regulate the flow. The adhesive should be spread in an even film. A scrap piece of carpet can be used to help spread an even film. Allow the adhesive to set open 1-2 minutes, and then lay pad immediately.

Walk pad into the adhesive, making sure to apply pressure at the seams.

Cleanup

Remove wet adhesive residue with a clean, white cloth dampened with soapy water. Use mineral spirits for dried adhesive residue. When using mineral spirits, carefully follow the recommendations of the manufacturer, and test a small area before proceeding to make sure it does not damage the surface being cleaned.

Warranty

10-Year Limited HENRY'S Best Warranty. Failure to follow written directions will void the warranty. For complete warranty details, please contact our Customer Service Center at 1-800-232-4832.

Notes

- FOR PROFESSIONAL USE ONLY.
- Store adhesive at temperatures between 40 and 90°F (4-32°C). Do not freeze.
- Shelf life is 1 year, if unopened.
- VOC: 4 g/L, calculated and reported, SCAQMD 1168

Do not reuse container. Dispose of container and adhesive residue in accordance with federal, state and local waste disposal regulations. Do not flush adhesive down drains.

Precautions

Carefully read and follow all precautions and warnings on the product label. For complete safety information, please refer to the Material Safety Data Sheet (MSDS) available at www.wwhenry.com.

Made in the USA by The W.W. HENRY Company,
Aliquippa, PA 15001

© 2013 The W.W. HENRY Company, L.P. All rights reserved.